

Sharps Machine

VOLTAGE REQUIREMENTS

- 50A/480V/3Ø

UNIT MEASUREMENT

- 121" H x 105" L x 92" W



Unit can be installed either indoors or outdoors.

FEATURES:

The **San-I-Pak Sharps Machine** effectively grinds treated, full Sharps Containers to the "unrecognizable" standard. The system uses a high-torque, low speed process, full monitored by the PLC for jams. The system will reach within 8/1000th of a second to blockage. This reduces the likelihood of damaging shredder teeth or the motors for the system. The output of the system is discharged into a cart for dumping into the compactor.



SCAN ME

Contact us today for more information

info@sanipak.com • 209.836.2310 • www.sanipak.com